

WAVING CLAMP FOR ELEMENT

Please see the Assembly machine and find out the original waving clamp was which type
Please Tell us which type and what size you want



square type

FOR OLD TYPE 90/min

Size 3 ~8 1003&1004

FOR Hispeed TYPE 120/min include V-chip

Size 3 ~8 1003A&1004A



FOR LA100,LA101 10 only

round type

10*16	1003&1004 10*16
-------	-----------------

10*20	1003&1004 10*20
-------	-----------------

Very very old machine have 10*25L



For LA12 ~13~16 structure

12 station rubber index

L over 20L ~35L cannot use for 10 structure

Large square type

10*20	1003-13 10*20
10*25	1003-13 10*25
12.5*20	1003-13 12.5*20
16*25	1003-16 16*25
16*30	1003-16 16*30
16*36	1003-16 16*36



For LA18 ~22 structure 8 station rubber index only

EXTRE high L structure 20L~40L

Size

round funnel type

12.5*20	1003AB 12.5*20
16*25	1003AB 16*25
18*30	1003AB 18*30

This type haven't for 10 yet